


VIVOSUN

4L COOL MIST HUMIDIFIER

INSTRUCTION MANUAL



Timer



MIST



Light

IMPORTANT


Please read this manual before you start using the device to see all its functions and use them in accordance with intended use.

1. Do not repair or modify the device. Only an authorized service technician is allowed to perform these operations.
2. Do not switch the device on if you have noticed any damage. This applies to wire and plug as well.
3. Do not use the device when it acts up, has been dropped or wetted, overheats extensively, is discolored or deformed, emits abnormal sounds, odors and when other atypical circumstances occur. This being the case, contact the manufacturer's authorized service center immediately.
4. If you do not use the device for a long period of time, unplug it.
5. The device is adapted to home use only. Do not use it outdoors.
6. Never leave the plugged device unattended.
7. This device is not a toy. Do not let children play with it.
8. Do not grab a wire to pull or move the device. Do not place any items on the device. Do not pull the wire through sharp edges of walls and furniture and do not wrap it too tight.
9. Unplug the device after every use.
10. Do not use the device and do not touch a plug if your hands are wet
11. When filling with water, hold the device with both hands to avoid dropping.
12. When the device is operating, do not touch water in the device or any element under water.
13. Do not use the device when the tank is empty.
14. Do not add any anti-rust agents, anti-odor preparations, alcohol or detergents to the tank, otherwise you may damage the tank.
15. Before you start cleaning or moving the device, switch it off and unplug it.
16. Do not let water penetrate the base. It may damage electronic parts of the device.
- 17. Use demineralized water at temperature below 40°C only.**
18. The device must operate at room temperature. Do not switch the device on at low temperatures. Before you turn it on, leave the device at room temperature for at least 30 minutes.
19. Position the device on a flat and horizontal surface, and avoid slopes.
20. Use the device away from sources of heat, high temperatures, hot surfaces, direct sunlight, sources of ignition, naked flame, oils and sharp edges.
21. Do not use the device in an inflammable, explosive or toxic atmosphere.
22. To prevent moisture from accumulating, keep the device away from household appliances.
23. Do not use chemical products to clean the device.
24. Every time you use aromatherapy oils, wash and rinse the tank, base and steamer carefully.
25. Do not use the device for other purposes than intended.
26. Do not move or push the device if the tank is filled with water.

ENVIRONMENT FOR USE


1. Place the device at least 2 meters from TV set, audio equipment and other electric devices.
2. Position the device on a flat and horizontal surface, and avoid slop
3. Do not place the device near curtains and furniture.
4. Place the device away from sources of heat, high temperatures, hot surfaces and direct sunlight.

PRODUCT DESCRIPTION



HANDLING AND OPERATION

Do not direct the cool mist vapor flow at walls or furniture which are sensitive to moisture. Please adjust the vapor flow to the required comfort level and to suit the size of the room.



FILLING INSTRUCTIONS



1. Remove the mist outlet. Grab the handle on the water tank to remove the water tank from the base.



2. Invert the water tank and remove the filter cap by turning it counter clockwise. Fill the water tank with clean cool water.




3. Put back the filter cap on. Place the tank correctly on the base and secure the nozzle on the water tank.



4. If you would like to use the aroma diffuser function, drop some essential oil in the aroma diffuser tray. Do not put essential oil directly into the water tank.

OPERATING INSTRUCTIONS

1. Connect the power cable plug into a power outlet of the correct specification. The LED display will light up for 1 second. Turn on the humidifier by pressing the ON/OFF button. Mist on level 3 (High mist). LED light is on.



2. Adjust the humidification flow rate among High/Medium/Low by pressing the MIST +/- button. The High setting will produce the maximum moisture level, while the Low setting will produce the longest run time and quietest performance.



High (3)



Medium (2)




Low (1)

3. Timer Setting

To shut off the humidifier automatically after running a defined time interval, press the TIMER button to select your desired time interval of 1, 2, 4 or 8 hours.

The timer icon will appear on the LED display to indicate the timer is active.


To cancel the timer feature, press the TIMER button until no numbers are displayed.



4. LED Light


Press the LIGHT button and the internal LED light will light up. Then Press the LIGHT button again, the internal LED light will off.

5. LED Display


Press and hold the LIGHT button for 2 seconds, the LED display turn off. Then press any button (except ), the LED display turn on.

-Indoor temperature

The LED display will show indoor temperature when the humidifier is on. Temperature and Humidity will change automatically.



REMOTE CONTROL



Remote control keys play the same role as their equivalents on the panel.


CARING FOR THE OSCILLATOR

1. Remove the mist outlet and water tank.
2. Wipe off the excess water from the humidifier base.
3. Use a soft toothbrush to clean the metal surface of the oscillator.
4. Rinse well with fresh water.
5. Dry completely.

CLEANING THE WATER TANK

1. Remove the mist outlet and water tank.
2. Remove the filter cap.
3. Clean the tank with a diluted vinegar solution.
4. Rinse extremely well, taking care not to leave any cleaning residue in the tank.
5. Dry completely.
6. Store in original packaging if the humidifier will not be used for along period of time.

CLEANING THE FILTER



1. Remove the mist outlet and water tank.
2. Invert the water tank and turn the filter cap counterclockwise.
3. Remove the cap and the attached filter.
4. Turn the filter clockwise from the filter cap.
5. Remove the filter and rinse well with fresh water.

Wash the filter under tap water every week.

TROUBLESHOOTING

Problem	Possible Cause	Solution
LED screen is not on, no mist.	Not plugged in.	Plug in the power cord and turn on the humidifier.
	Water valve is stuck.	Clean the water valve and press the water valve head gently to make it work.
Mist has an odor.	New humidifier.	Unscrew the tank cap on the water tank and place it in a cool dry place for 12 hours.
	Unclean water or water has been in the tank a long time.	Clean the water valve and refill with clean water.
Minimal mist output.	Deposits on or around oscillator.	Clean the oscillator.
	Unclean water or water has been in the tank a long time.	Clean the water tank and refill with clean water.
LED screen is on, no mist.	No water in the Water tank.	Fill the water tank.
	Humidifier is not on.	Turn on the humidifier.
	Water valve head is loose.	Press and tighten the water valve head.

LIMITED WARRANTY

This item is warranted to be free from defects in materials or workmanship for a period of 30 days from the original date of purchase under normal conditions of intended use. If this product is defective, Warrantor will, within the warranty period, replace the product or refund the purchase price of the product, at Warrantor's option, at the place of purchase upon presentation of sales receipt or other proof of purchase. This warranty extends only to the original retail purchaser and excludes any damage to the product resulting from accident, misuse, abuse, damage caused by electrical power surge, or operation not recommended or authorized by these operating and safety instructions. This warranty is voided if the product is ever used in a commercial or business environment.

There are no warranties beyond this limited warranty. This limited warranty is your complete and exclusive remedy. Warrantor makes no other warranties, express or implied, including but not limited to any implied warranty of merchantability or of fitness for a particular purpose. Warrantor undertakes no responsibility for the quality of the product except as otherwise provided herein. Warrantor assumes no responsibility that the product will be fit for any particular purpose for which you may be buying this product. Warrantor expressly disclaims liability for any special, incidental, indirect, or consequential damages arising from the purchase or use of this product.

The amount of Warrantor's liability under this warranty is limited to the amount of the original purchase price paid for the product by the original retail purchaser. If Warrantor cannot lawfully disclaim statutory or implied warranties, then all such warranties shall be limited to the duration of this warranty and to the amount of the original purchase price paid for the product by the original retail purchaser.

This warranty gives you specific legal rights; you may also have other rights that vary by jurisdiction. This warranty is valid only within the United States of America (USA) and Canada.

VIVOSUN

4L COOL MIST HUMIDIFIER



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Notes



Returns & Refunds

Designed by **VIVOSUN** in California

Made in P.R.C