


# VIVOSUN



**Portable Electric Heater**

**USER MANUAL**

# Love what you grow™

Welcome to **VIVOSUN**

Thank you for choosing VIVOSUN. We are committed to product quality and friendly customer service. If you have any questions or suggestions, please don't hesitate to contact us.

# CONTENTS

Safety Instructions .....	1
Assembly .....	5
Electrical Ratings .....	5
Parts and Features .....	5
Operating Instructions .....	5
Heat Mode Setting .....	6
Fan Mode Setting .....	6
Thermostat Control .....	6
Safety Features .....	7
Reset Instructions .....	7
Operational Failure .....	7
Care and Maintenance .....	8
Specifications .....	8

# SAFETY INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS. KEEP FOR FUTURE REFERENCE. FOR HOUSEHOLD USE ONLY.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet ( 0.9 m) from the front of the heater and keep them away from the sides and rear.

## **WARNING:**

Use this heater only for its intended purpose. Do not use the heater for any purpose not authorized by the manufacturer as this may result in fire, electric shock, personal injury or property damage.

- Use extreme caution when this heater is operated near children or individuals with special needs. Do not leave the heater unattended while in use.
- Always unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard the heater, or return it to an authorized service facility for examination and/ or repair.
- Do not use the device outdoors.

# SAFETY INSTRUCTIONS

- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never place the heater where it may fall into a bathtub or other water container.
- Do not run or hide the power cord under carpets, rugs, runners or furniture. Keep the cord visible and away from high traffic areas where it could pose a tripping hazard.
- To disconnect the heater, turn the controls to the off position, then remove plug from outlet. Never pull by the cord.

## **NOTE:**

The heater plug and power cord will be warm to the touch after use. This is normal and does not affect the heater's performance in any way.

## **WARNING:**


- In order to avoid overheating, do not cover the heater.
- Do not place the heater directly under an electrical outlet.
- Do not use this heater in the immediate surroundings of a bath, shower or swimming pool.
- This heater draws 12.5 amps during operation. To prevent overloading a circuit, do not plug the heater to a circuit where other appliances are in use.
- Do not insert or allow foreign objects to enter any ventilation or exhaust openings as this may cause an electric shock, fire, or damage to the heater.
- To prevent a potential fire hazard, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

# SAFETY INSTRUCTIONS

- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or personal injury.
- **CAUTION:** It is normal for the plug to feel warm to the touch; however, a loose fit between the AC outlet (receptacle) and the plug can cause overheating and distortion of the plug. Contact a qualified electrician to replace a loose or worn receptacle.
- **CAUTION:** Always plug heaters directly into a wall outlet/ receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip)
- Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, tiredness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, turn off the heater and seek immediate medical attention.
- To avoid excessive room temperatures that can cause hyperthermia: DO NOT leave the product running unattended in a confined space around infants, or individuals with reduced physical, sensory, or mental capabilities.
- **CAUTION:** TO PREVENT ELECTRIC SHOCK, MATCH THE WIDE BLADE OF THE PLUG TO THE WIDE SLOT AND INSERT FULLY.
- The output of this heater may vary and its temperature may become high enough to burn exposed skin. Use of this heater is not recommended for people with reduced sensitivity to heat or an inability to react to or avoid burns.

# SAFETY INSTRUCTIONS

- **CAUTION:** Please note that this appliance comes with a polarized plug, where one blade is wider than the other. To minimize the risk of electrical shock, this plug is designed to fit into a polarized outlet in one specific orientation. If you encounter difficulty inserting the plug fully into the outlet, attempt to reverse the plug. If it still does not fit, it's essential to consult a qualified electrician for assistance. **DO NOT** attempt to bypass or modify this safety feature, as doing so could result in hazardous electric shock.



## **WARNING - Risk of Heat Stroke (Hyperthermia)**

Hyperthermia can be fatal to infants and vulnerable individuals. Exercise extreme caution to avoid overheating. Before use, thoroughly read and follow all safety instructions. **REMOVE BEFORE USE!**



**CAUTION: RISK OF ELECTRIC SHOCK. DO NOT OPEN. NOT USER-SERVICEABLE. PARTS INSIDE.**

## **WARNING:**

To reduce the risk of shock, this plug is intended to fit only one way into the polarized outlet. If the plug does not insert fully into the outlet, try inserting it upside down. If the plug still does not fit, contact your electrician to replace the outlet.

Do not attempt to repair the power cord or outlet. Doing so may cause electric shock.


## ASSEMBLY

This unit comes fully assembled from the manufacturer. No assembly is required before use.

## ELECTRICAL RATINGS

This product is rated 12.5 amps (1500W) at 120V,60Hz.

## PARTS AND FEATURES



- A Thermostat Control
- B Power and Setting Control
- C Power Indicator Light

Place the heater on a firm, level surface free of obstructions, and at least 3 ft. (0.9m) away from any wall or combustible material.

## OPERATING INSTRUCTIONS


- Before using the heater, make sure that it is placed on a flat and stable surface. Do not operate the unit on an uneven or angled surface.
- Avoid overloading your circuit by not using other high wattage appliances in the same outlet. At 1500 Watts, this unit draws 12.5Amps. Only plug this heater into a dedicated electrical outlet rated for at least 15 Amps.



## HEAT MODE SETTING

- To begin heating, turn the Thermostat control clockwise to the maximum setting.
- Turn the power and setting control to your desired heat setting:
  - 1-700W
  - 2-900W
  - 3-1500W
- The power light will remain on during operation.

## FAN MODE SETTING

To use the unit as a cooling air circulator without heat, turn the power fan setting control to 

## THERMOSTAT CONTROL

- Turn the thermostat control clockwise to the highest position to start the heater. Allow heater to operate and warm up the room.
- When the desired temperature/comfort level is reached, lower the temperature setting by turning the Thermostat Control counterclockwise until the heater stops operating.
- The thermostat will automatically maintain the pre-set temperature level by turning the heat ON and OFF.

**NOTE:** It is normal for the heater to cycle ON and OFF as it maintains the preset temperature. To prevent the unit from cycling, raise the temperature setting.

## SAFETY FEATURES

**Thermal Cut-off:** This heater includes a thermal cut-off that shuts the heater off if it overheats due to abnormal conditions. If this occurs, turn the heater off, unplug it, inspect and remove any objects on or adjacent to the heater. Allow it to cool for a few minutes, and then plug it back in and resume normal operation. Note: This is not a defect!

**Tip Over Switch:** This heater includes a safety tip over switch, which will shut the heater off in case it is tipped over. If at any time, the heater does tip over, please place the heater back in the upright position. The heater will then resume normal operation.

## RESET INSTRUCTIONS

If the unit shuts down, please follow these instructions:

1. Turn the power off
2. Unplug the unit and wait 10 minutes
3. Plug in and turn on

## OPERATIONAL FAILURE

- Make sure it is plugged in and that the electrical outlet is working.
- Check for any obstructions. If you find an obstruction, turn the heater OFF. Unplug the heater and wait at least ten minutes for it to cool. Carefully remove the obstruction. Plug the heater back in and restart it as described under OPERATION.
- If the unit is operating the same as mentioned above, remove the plug from the socket and have it serviced by an authorized electrician only.

# CARE AND MAINTENANCE

For optimal performance, clean this heater at least once per month while in use. Additionally, thoroughly clean the unit before storing it away for the off-season.

- Turn the heater OFF and unplug it. Allow it to cool.
- Use a dry cloth to clean the external surfaces of the heater.

**DO NOT USE WATER, WAX, POLISH OR ANY CHEMICAL SOLUTION.**

- Clean your heater using the above-mentioned steps, then pack the heater in its original container and store in a cool dry place.
- This heater does not disassemble.
- The motor has permanent factory lubrication that will last for its entire lifespan. No additional lubrication is required.

# SPECIFICATIONS

Model	EH-0003
Voltage	120V 60Hz
Current	Maximum continuous draw: 12.5 Amps
Power	1=700W 2=900W 3=1500W
Tolerances on all specifications	Not in excess of 105%

Designed by **YIVOSUN** in California.  
Made in China